



ZOOM-ZOOM

MZD CONNECT

GLOBALĀS BALSS KOMANDAS

Globalās balss komandas var izrunāt jebkur sistēmā. Izmantojiet tās, lai viegli pārvietotos pa saziņas, izklaides un navigācijas funkcijām un arī lai saņemtu vispārīgu palīdzību par sistēmas izmantošanu.

Cancel
Go back
[Go to] (home [screen] | main menu)
Next
Previous
Play | resume
Pause | stop
[Turn] (display | screen) off
Clock display
Tutorial
Page down
Page up
Help
Line <linenumber>
[Go to] communication | [go to | show] message | messages
[Go to | show] (messages | notifications)
Entertainment
[Go to] navigation
[Go to] settings
[Go to | show] contacts | [go to | show] phonebook
[Go to | dial] phone
([Go to | show] [call] history) | ([go to | show] recent calls)
[Go to] text | [go to] SMS
[Go to | play] Aha [radio]
[Go to | play] AM [radio]
([Go to | play] line in) | ([go to | play] auxillary) | ([go to | play] AUX)
[Go to | play] Bluetooth [audio]
([Go to | play] CD [player]) | ([go to] compact disc)
[Go to | play] FM [radio]
[Go to | play] Stitcher
[Go to] applications
[Go to | play] USB [audio]
[Go to | play] USB 1
[Go to | play] USB 2

Dial pad
Call | dial
(Call | dial) [by] number
(Call | dial) [by] name
(Call | dial) <phoneNumber>
Call <contactName> [<phoneType>]
Call back
Redial
Browse [playlist] <playlistName>
Browse [artist] <artistName>
Browse [album] <albumName>
Browse [genre] <genreName>
Browse [folder] <folderName>
Browse
Browse song
Browse playlist
Browse artist
Browse album
Browse genre
Browse folder
Play song
Play playlist
Play artist
Play album
Play genre
Play audiobooks
Play podcasts
Play folder
Play [playlist] <playlistName>
Play [artist] <artistName>
Play [album] <albumName>
Play [genre] <genreName>
Play folder <folderName>
Address | navigate to [an] address | [enter | drive to] new address
(Clear | cancel) route
(Tune to | station) [AM | FM] <stationFrequencyAM> [AM | FM]
Tune to <satChannelNumber>